

ZEKE-9-12V-SQR

Date: 02/2020

| Order Code | Product Code | Description |
|------------|-----------------------|---|
| 19878 | ZEKE-9-12V-SQR-BLK-WW | Black, Square Exterior Wall Light, 3000K Warm White |
| 19879 | ZEKE-9-12V-SQR-BLK-W | Black, Square Exterior Wall Light, 5000K White |
| 19872 | ZEKE-9-12V-SQR-SLR-WW | Silver, Square Exterior Wall Light, 3000K Warm White |
| 19873 | ZEKE-9-12V-SQR-SLR-W | Silver, Square Exterior Wall Light, 5000K White |
| 19874 | ZEKE-9-12V-SQR-DGR-WW | Dark Grey, Square Exterior Wall Light, 3000K Warm White |
| 19875 | ZEKE-9-12V-SQR-DGR-W | Dark Grey, Square Exterior Wall Light, 5000K White |
| 19877 | ZEKE-9-12V-SQR-WHT-WW | White, Square Exterior Wall Light, 3000K Warm White |
| 19876 | ZEKE-9-12V-SQR-WHT-W | White, Square Exterior Wall Light, 5000K White |

Thank you for purchasing your new LED ZEKE-9-12V-SQR, Please take the time to read and understand the instruction sheet below. Failure to do so may void warranty.


Specifications

| | | | | | |
|------------|------------------------------------|--------------|-------------------------------------|-----------|-----------|
| Voltage: | 12V DC | Lumen (±5%): | Warm White - 800lm White - 900lm | Dimmable: | No |
| Power: | 9W | Beam Angle: | 120° | Lifespan: | 50,000hrs |
| IP Rating: | 65 | CCT: | 3000K - 5000K | CRI: | ≥85 |
| Requires: | 12V DC Constant Voltage LED Driver | | | | |

Steps:

Please make a visual inspection to the fixture prior to installation. If any defect is to be found please return to you place of purchase for a replacement.

Make sure all power is correctly turned off from the mains and NOT just from the switch.



Wire in Parallel

Note: -The lamp must be installed by professional electrician
-Ensure the power supply is switched off before fitting this product

-Do not touch the lamp when in use
-Keep away from hot steam and corrosive gas