AVOCA DC Series Installation Guide

Thanks for choosing our Avoca DC Series ceiling fan.

We strongly recommend that you read this manual carefully before installation.

Models Parameters (Fan Only):-

MVDC134M 1320mm 4 Blade DC WiFi Ceiling Fan Matt Black MVDC134W 1320mm 4 Blade DC WiFi Ceiling Fan Matt White



Part List:

Qty 1x Remote kit Qty 4x Blades

Models Parameters (Fan and LED Light):-


MVDC1343M 1320mm 4 Blade DC WiFi Ceiling Fan Matt Black with LED light MVDC1343W 1320mm 4 Blade DC WiFi Ceiling Fan Matt White with LED light

Part List:


Qty 1x Motor assembly Qty 1x Instruction manual Qty 1x Screw kit Qty 1x Hanging Bracket

Qty 1x Remote kit Qty 4x Blades Qty 1x LED light kit

Application



How to Assemble





How to Install Blades




Attach the blade to the top of the motor using the 2 screws provided. Tighten the screws and repeat this procedure for all blades.




NB: Ensure the blades do not get damaged or bent during the installation process while the fan is on the ground. This will affect the performance and balance of the fan and this is NOT covered under warranty.

How to Install




How to Install Light Plate






How to Install / Remove the Cover

Fg.8 Fan Only Model




Carefully install the bottom cover onto the fan by pushing and twisting as illustrated.

Fg.9 Fan LED Light Model



Align the convex point on the light plate with the gap on the LED mounting plate and press down firmly.

Installing Receiver Remote Control




Wire up the receiver with quick connectors and insert into the mounting bracket. Make sure the antenna wire has been safely folded inside the canopy cover before nal assembly. (DO NOT cut the antenna wire)

Important Reminders

- Receiver must be correctly installed in the mounting bracket
- When the transmitter cannot control the receiver, please check
 - i) has su cient battery in the transmitter
 - ii) any existence of similar remote controlled products nearby that cause interference
- Replace battery if getting low as this will a ect sensitivity of the transmitter
- Take the battery out from the transmitter when leaving used for a long time to avoid battery leaks
- Isolation switch MUST be connected in the line



Wire Connections



6* Year Warranty

https://www.martecaustralia.com.au/wp-content/uploads/ Visit our website for details 2023/05/Warranty-Statement_Cooling.pdf







WARNING

- Installation of fans MUST follow SAA standards and meet local authority regulations.
- Installation MUST be carried out by a qualified and licensed electrician.
- Fan and light MUST be earthed.
- Bracket MUST be firmly attached to a flat solid structure or timber frame.
- DO NOT mix blades from one model to another, all blades MUST be replaced if damaged.
- The warranty is **VOID** if product is not installed according to this installation guide.



Smart Life matching process, please follow the steps:

1.Download the "Smart Life" APP on your smart devices by scanning the QR code below with camera.



- 2.Turn on WiFi and Bluetooth on your smart devices. Ensure it's connected to a 2.4GHZ WiFi.
- 3. Open the APP, follow the steps to register new user account or login existing account.



- 4.Follow instructions in main manual (steps can also be found on the back of the remote) to put the fan into WiFi pairing mode. If the operation is successful, go to step 5. If the fan has previously been paired or you can't get it to work, please go to step 4 to RESET the fan.
- 5.RESET the fan. This step is NOT necessary if the fan has successfully entered WiFi pairing mode in the last step, if not, try to RESET the fan: turn on the fan, power off after 10 seconds, power on again after 15 seconds, long press "Fan Stop" for 5 seconds, if "beep beep" are heard, the reset is successful. If "beep beep" is not heard, the reset is failed, please repeat this step.

6.Once the fan has entered WiFi pairing mode, open the APP again on the smart device. Click "Add Device" in the middle or the "+" on the top right of the screen.




7. The auto scan should begin automatically, and the fan should show up at the top of screen within a few seconds.

Note: If the fan is not showing up, you can add it manually by clicking and navigate to: >Add Manually >Small Home Appliance > Fan









WiFi / Remote Control Pairing

Fan only model

Pairing the remote control

- 1. Turn on the ceiling fan.
- 2. Within the first 20 seconds, continue pressing the (1) button until you hear a "beep" sound. ie. It is paired.

If you don't hear a "beep" sound, repeat step 1 and step 2 again.

Entering WiFi Pairing mode:

- 1. Turn on the power.
- 2. Within the first 20 seconds, press and " button until a "beep" hold the " is heard.
- 3. Continue step connect on your smart devices to complete the pairing.

If you don't hear a "beep" sound, repeat the above steps.

FAN OFF (1): to switch off the fan.

SLEEP MODE : Turn on the fan at an extra lower speed to create a general breeze.

SPEED BUTTON: 1 = lowest speed. 6 = highest speed.

NATURAL WIND MODE : designed for the elderly and children. 1-6 speed changes randomly to feel the breeze.

FORWORD AND REVERSAL (): summer/winter reverse mode.

TIMER 1H/4H/8H: preset timer for fan and light to stop automatically. ie. if timer set at 1H and then press 4H, fan will stop at 4H. Setting default to last press.

WIFI BUTTON 🛜 :Follow the instructions and press and hold for 20 seconds to enter wifi matching mode.

Fan LED Light Model

Pairing the remote control

- 1. Turn on the ceiling fan.
- 2. Within the first 20 seconds, continue pressing the (1) button until you hear a "beep" sound. ie. It is paired.

If you don't hear a "beep" sound, repeat step 1 and step 2 again.

Entering WiFi Pairing mode:

1. Turn on the power.

2. Within the first 20 seconds, press and " button until a "beep" hold the " -<u>:</u>Ö:is heard.

3. Continue step connect on your smart devices to complete the pairing.



If you don't hear a "beep" sound, repeat the above steps.

FAN OFF (1): to switch off the fan.

SLEEP MODE : Turn on the fan at an extra lower speed to create a general breeze.

SPEED BUTTON: 1 = lowest speed. 6 = highest speed.

NATURAL WIND MODE : designed for the elderly and children. 1-6 speed changes randomly to feel the breeze.

FORWORD AND REVERSAL (): summer/winter reverse mode.

TIMER 1H/4H/8H: preset timer for fan and light to stop automatically. ie. if timer set at 1H and then press 4H, fan will stop at 4H. Setting default to last press.

LIGHT ON/OFF - : to switch off the light.

CCT: warm white (2700K) / netural white (4000K) / cool white (6500K)

LED- LED+: minus "-" = reduces brightness plus "+"= increases brightness

6* Year Warranty Visit our website for details https://www.martecaustralia.com.au/wp-content/uploads/ 2023/05/Warranty-Statement_Cooling.pdf

1h 4h 8h

/// MARTEC







WARNING

- Installation of fans MUST follow SAA standards and meet local authority regulations.
- Installation MUST be carried out by a qualified and licensed electrician.
- Fan and light MUST be earthed.
- Bracket MUST be firmly attached to a flat solid structure or timber frame.
- DO NOT mix blades from one model to another, all blades MUST be replaced if damaged.
- The warranty is VOID if product is not installed according to this installation guide.



